

Date: February 2021
Rev: VIII
No. of Components: Two
Mix Ratio by Weight: 10 : 1
Specific Gravity: Part A: 1.12 Part B: 1.15
Pot Life: 3 Days
Shelf Life- Bulk: Six months at room temperature

Biocompatible Certified Cure: 150°C / 45 Minutes

Alternative biocompatible cure schedules may be possible, but have not been certified. Contact med@epotek.com with any questions.

NOTES:

- Container(s) should be kept closed when not in use.
- Filled systems should be stirred thoroughly before mixing and prior to use.
- Performance properties (rheology, conductivity, others) of the product may vary from those stated on the data sheet when bi-pak/syringe packaging or post-processing of any kind is performed. Epoxy's warranties shall not apply to any products that have been reprocessed or repackaged from Epoxy's delivered status/container into any other containers of any kind, including but not limited to syringes, bi-paks, cartridges, pouches, tubes, capsules, films or other packages.
- Component suppliers assure Epoxy that all components are supplied in compliance with ISO 22442. Sales of EPO-TEK® MED-354-T shall accordingly require Epoxy's Standard Specification document to be signed as a technical agreement thereunder.

Product Description: EPO-TEK® MED-354-T is a biocompatible, high Tg, thixotropic version of EPO-TEK® MED-354 epoxy. It is electrically and thermally insulating and formulated for medical applications with fiber optics, optoelectronic assemblies, as well as semiconductor packaging.

Typical Properties: Cure condition: 150°C / 45 Minutes Different batches, conditions & applications yield differing results.
 Data below is not guaranteed. To be used as a guide only, not as a specification. * denotes test on lot acceptance basis

PHYSICAL PROPERTIES:			
* Color (before cure):	Part A: Tan	Part B: Amber	
* Consistency:	Smooth thixotropic paste		
* Viscosity (23°C) @ 20 rpm:	11,000-20,000	cPs	
Thixotropic Index:	3.0		
* Glass Transition Temp:	≥ 95 °C (Dynamic Cure: 20-200°C/ISO 25 Min; Ramp -10-200°C @20°C/Min)		
Coefficient of Thermal Expansion (CTE):			
	Below Tg:	54	x 10 ⁻⁶ in/in°C
	Above Tg:	161	x 10 ⁻⁶ in/in°C
Shore D Hardness:	80		
Lap Shear @ 23°C:	> 2,000	psi	
Die Shear @ 23°C:	≥ 15	Kg	5,334 psi
Degradation Temp:	421 °C		
Weight Loss:			
	@ 200°C:	0.24	%
	@ 250°C:	0.52	%
	@ 300°C:	1.10	%
Suggested Operating Temperature:	< 350 °C (Intermittent)		
Storage Modulus:	442,736	psi	
* Particle Size:	≤ 20 microns		

Epoxyes and Adhesives for Demanding Applications™

This information is based on data and tests believed to be accurate. Epoxy Technology, Inc. makes no warranties (expressed or implied) as to its accuracy and assumes no liability in connection with any use of this product.

EPOXY TECHNOLOGY, INC.

14 FORTUNE DRIVE, BILLERICA, MA 01821 (978) 667-3805, FAX (978) 663-9782

www.epotek.com

Selected Applications for EPO-TEK® MED-354-T

Fiber and Electro-Optics

- Adhesion to plastic and glass optical fibers, structural and near hermetic sealing of glass, ceramic and metals
- Manufacture of all kinds of endoscopes, such as, laryngoscopes, gastroscopes, broncho-scopes and micro ophthalmoscopes; healthcare optics for colonoscopy, urology, and otolaryngology
- Fiber optic enabled OCT imaging delivered via catheter
- Fiber optic adhesive for surgical lighting and optics including loupes and endoscopic aftermarket repair adhesive

Ultrasound / Ultrasonic

- Adhesive for catheter delivered surgical mapping, 3D imaging and mapping catheters; catheter ultrasound for cardiac therapy, such as AFib treatments
- Screen printable epoxy for back-end PZT processes enabling transducers, with adhesion to thin metal foils
- Repair adhesive for ultrasound probe

Life Sciences and MicroFluidics

- DNA and gene sequencers, readers and amplification circuits
- Water purity, testing, monitoring and flow delivery systems

Device and Diagnostics

- Sensor integration and subcomponents for respiratory, anesthesia, vapor and suction; gas and liquid flow monitoring
- Irrigation and pharmaceutical delivery via ultrasonic nebulizers
- Adhesive for anesthesia and gas analyzers and flow meters

Surgical Tools

- High power laser optics for general, reconstructive and cosmetic surgery
- Fabrication of Rf Ablation catheters
- Electro-surgical tool for tissue removal; adhesion to ceramic, SST and plastics
- Single use microwave ablation probes for tumor removal
- General catheter delivery and extraction tools
- Fiber Optic laser enabled biopsies

Biocompatibility Approvals

- EPO-TEK® MED-354-T cured at 150°C for 45 minutes has been tested and is ISO 10993-5 certified (Cytotoxicity testing by MEM Elution methodology).

Sterilization Information

- Epoxy performance is most influenced by surface preparation and cleanliness, overall process and handling, and finally proper curing selection. While bulk samples of MED-354-T may resist sterilization technologies such as autoclave steam, gaseous technologies, gamma radiation as well as liquid disinfectants, the glue joints may differ. All users need to determine the suitability of MED-354-T for their given application.
 - MED-354-T was found compatible with 100 cycles of Sterrad® sterilization cycles at standard concentration.
 - MED-354-T is generally regarded for resisting few cycles of ETO and gamma radiation.
- See Technical Tip # 29: Gamma Sterilization for Medical Devices and its Effect on Epoxies for more information:
http://www.epotek.com/site/files/Techtips/pdfs/techtips_29.pdf

Packaging Availability

- EPO-TEK® MED-354-T is available in specialty packaging such as Pre-Mixed Frozen (PMF), Bi-Paks, or bulk (A & B containers).
- A Bi-Pak video tutorial can be found here:
<http://www.epotek.com/site/technical-material/application-video-tutorials/117-effective-handling-and-mixing-of-epo-tek®-bi-packs.html>
- A video tutorial on handling frozen syringes can be found here:
<http://www.epotek.com/site/technical-material/application-video-tutorials/231-proper-receiving-and-thawing.html>



Epoxy Technology Inc.
 14 Fortune Drive • Billerica, MA 01821
 phone 978-667-3805 fax 978-663-9782
 med@epotek.com